10W, 20W, 50W Flood Light
Remote Instructions

Step by Step:

1. Please charge the light/solar panel for 24 hours prior to turning on. Install 2 AAA batteries in your remote.
2. Press and hold the red button on the fixture for four seconds to turn on. At this point, the light will work from dusk until dawn with no need to utilize the remote. The indicator light on the fixture should be red.
3. If you would like to utilize the remote options, do so as follows:

Outdoor Mode Remote Options: (Red Indicator Light)

1. Rainy Mode – 60% Brightness
2. Cloudy Mode – 80% Brightness
3. Sunny Mode – 100% Brightness

Indoor Mode:

To switch from Outdoor Mode to Indoor Mode, give the red fixture power button a short press. The indicator button on the fixture should now turn green.

Indoor Mode Remote Options
(Bypassing Photocell – Green Indicator Light):

1. Reading Mode – 100% Brightness
2. General Mode – 80% Brightness
3. Atmosphere Mode- 60% Brightness

Additional Remote Options:

Lightbulb with +: Step up brightness by 10%

Lightbulb with -: Step down Brightness by 10%

5H: Set the timer for 5 hours

3H: Set the timer for 3 hours